Developed for Healthcare Fights Infection Rates

Sustainable Eco-Friendly Cleaners and Coatings That Save You Time and Money

# Bright, Clean and Healthy Floors™

# TOC - Me

#### TIO2 EL OOR TREATMEN

CONCENTRATE MAKES 5 GALLONS
MODEST SLIP OD-ETYCHIST + DOES NOT SUSTANI INCREDIAL PROPAGATION + NEVER YELLOW, CHE, PREL CR.











## FIRST TIME Preparation and Application Instructions

#### **TOOLS & SUPPLIES NEEDED**

- Medama TIO2 Floor Treatment
- Recommended Stripper (Medama GenX Stripper)
- Medama TIO2 Cleaning Powder
- Autoscrubber/Floor buffer and wet vac
- Burnisher 2000 RPM or higher
- Mop bucket and clean mops
- Flat applicator micro-fiber mop 18-36 inch
- Medama Diamond Burnishing Pads (400/800/1500/8000 Grit)
- Pump sprayer
- Air movers/blowers/fans

### **Prepare The Floor**

- 1. Thoroughly strip floor whether it's old or factory new using Medama 220 Grit Diamond Pad and Medama GenX Stripper. Remove all shiny spots and old wax around the edges.
- 2. Vacuum up wet residue. Do not allow residue to dry.
- 3. Flood floor using a mixture of 1 large scoop of Medama TIO2 Floor Treatment in 4 gallons of water, using a 220 Grit Medama Diamond Pad and autoscrubber to agitate slurry.
- 4. Burnish the floors using Medama Diamond Pads. If floors are older and damaged, start with a 400 Grit pad (wet) and work the floors. If the floors are new start with a 1500 Grit pad (dry)
- 5. Vacuum up all slurry and add plain water to floor, while continuing to agitate until water is clear.

#### **Apply Medama TIO2 Floor Treatment**

- 6. Apply 2 coats of Medama TIO2 Floor Treatment (1 part TIO2 and 2 parts water). Allow to dry between coats (use fan or blower if necessary)
- 7. Burnish with Medama 1800 Grit Diamond Pad while spray buffing using 1 quart of water and 1/4 nano scoop of Medama TIO2 Cleaning Powder mixture.
- 8. The following 10 coats will be mixed at 1 part TIO2 and 3 parts water. Medama TIO2 Floor Treatment needs to dry between coats.
- 9. Burnish floor with Medama 1800 Grit Diamond Pad and then burnish with Medama Polishing Pad.















## **Recoating Instructions**

#### **TOOLS & SUPPLIES NEEDED:**

- Medama TIO2 Floor Treatment
- Medama TIO2 Cleaning Powder
- Autoscrubber or buffer
- Burnisher 2000 RPM or higher
- Mop bucket and clean mops
- Flat applicator micro-fiber mop
- 8000 Grit Medama Diamond Pad
- Pump sprayer
- Air movers/fans/blowers

### **Prepare The Floor**

- 1. If the floor has any dirty build up, clean using Medama TIO2 Cleaning Powder using a mop or autoscrubber
- 2. Liberally mop floors with a mixture of water and Medama TIO2 Cleaning Powder (1 large scoop per 4 gallons of water) using a damp mop or autoscrubber to remove any residue, then pick up residue with a wetvac or autoscrubber.
- 3. Final rinse using clear water and a mop or autoscrubber. Vacuum up residue.
- 4. Burnish the floor with an 8000 grit Medama Diamond Pad (Dry).
- 5. Dust mop

#### **Applying Medama TIO2 Floor Treatment**

- 6. Apply Medama TIO2 Floor Treatment at 1 part TIO2 and 3 parts water using a pump sprayer and flat micro-fiber applicator mop. Best done with 2 workers.
- 7. Allow to dry or accelerate drying with fans or blowers.
- 8. Apply a second coat of Medama TIO2 Floor Treatment using the same method.
- 9. Burnish after the second coat is dry with the 8000 Grit Medama Diamond Burnishing Pad.

Ace Janitorial Supply 1365 61 Street Brooklyn NY 11219 718-492-7200 f:718-492-3878 www.acejan.com

